










Nombre de modelo : AZQS100B8V1B

Clave de PL : ED91-14

Número	Referencia	Información	Descripción	Nota
A1	5008620		COMPRESSOR	
A2	0768508		COMPRESSOR MOUNTING BOLT	
A3	390215		SPRING HOLDER	
A4	390208		MOUNTING SPRING	
A5	0960397		SPRING HOLDER	
A6	390204		WASHER (NUT WITH WASHER)	
A7	0401393		PROTECTION BUSHING FOR LEAD WIRE	
A8	5014005		WIRE HARNESS ASSY	
A9	1262647		TERMINAL COVER	
A10	5008623		COMP.SOUNDPROOF	
A11	5008525		COMP.SOUNDPROOF	
B1	*		HEAT EXCHANGER	
B1.1	5013696		HEAT EXCHANGER ASSY	
B1.2	5008529		SEALING	
B2	*		FOUR WAY VALVE	
B2.1	5011758		FOUR WAY VALVE BODY	
B3	5008537		MUFFLER	
B4	1076389		CHECK VALVE	
B5	5008508		HIGH PRESSURE SWITCH	
B6	300567P		LOW PRESSURE SWITCH	
B7.1	1623709		STOP VALVE ASSY	
B7.2	5013697		VALVE CAP	
B7.3	250204		FLARE CAP PACKING	
B7.4	300076P		FLARE NUT 5/8	
B8	159974J		SERVICE PORT	
B9.1	300981P		STOP VALVE ASSY	
B9.2	0454328		STOP VALVE CAP	
B9.3	139571J		VALVE CAP	
B9.4	300074P		FLARE NUT 3/8	
B10	232025		FILTER	
B11	5008626		MOTOR OPERATED VALVE BODY	
B12	5013698		ACCUMULATOR ASSY	
B13	5008531		MOUNTING PLATE	
B14	0650304		WATER PROOF CAP	
B15	*		MULTIPLE SELECTION REQUIRED	
B15.1	5013991		REFRIGERANT PIPE	
B15.2	5013977		GREASE	
C1	5008502		PROPELLER FAN	
C2	847003		FAN RETAINING NUT	
E1	*		MULTIPLE SELECTION REQUIRED	
E1.1	*		EL.COMPO.ASSY(TOP)	
E1.2	065337J		CAPACITY SETTING ADAPTOR	
E1.3	5013977		GREASE	
E2	*		MULTIPLE SELECTION REQUIRED	
E2.1	5013702		MAIN PCB ASSY	
E2.2	065337J		CAPACITY SETTING ADAPTOR	
E2.3	5013977		GREASE	
E2.4	5013703		PCB SPACER	
E3	5013703		PCB SPACER	
E4	*		MULTIPLE SELECTION REQUIRED	
E4.1	5013705		PUSH BUTTON PCB ASSY	
E4.2	5013703		PCB SPACER	
E5	5013706		REACTOR (15A/300uH)	
E6	105030J		TERMINAL BLOCK HP-T3041-D3C3-L	
E7	*		MULTIPLE SELECTION REQUIRED	
E7.1	5013707		INSULATION SHEET	
E7.2	5014033		CAUTION LABEL	
E8	5013708		FOUR WAY VALVE COIL	
E9	1278534		MOTOR OPERATED VALVE COIL	
E10	5013992		THERMISTOR (AIR)	
E11	5008599		THERMISTOR ASSY	
E12	5013993		THERMISTOR (LIQUID)	

E13	5013994		WIRE HARNESS ASSY	
E14	5013995		WIRE HARNESS ASSY	
E15	5019123		WIRE HARNESS ASSY	
E16	5013997		WIRE HARNESS ASSY	
E17	5013998		WIRE HARNESS ASSY	
E18	5013999		WIRE HARNESS ASSY	
E19	5014000		WIRE HARNESS ASSY	
E20	5014001		WIRE HARNESS ASSY	
E21	5019124		WIRE HARNESS ASSY	
E22	5013709		HEATSINK COVER	
E23	5013710		HEATSINK COVER SCREWS	
E30	*		MULTIPLE SELECTION REQUIRED	
E31	*		MULTIPLE SELECTION REQUIRED	
E32	*		MULTIPLE SELECTION REQUIRED	
E34	*		MULTIPLE SELECTION REQUIRED	
E34.2	5014033		CAUTION LABEL	
E51	1571327		THERMISTOR FIXING PLATE	
E52	0423968		MOUNTING SPRING,THERMISTOR	
E53	5008532		FEELER BULB CLAMP	
E54	5013734		DC FAN MOTOR	
F1	5008536		TOP PLATE	
F2	5009203		FRONT PLATE 1	
F3	5008520		DISCHARGE GRILL	
F4	5013722		FRONT PLATE 2	
F5	5008613		RIGHT SIDE PLATE	
F6	5008614		REAR PLATE	
F7	5013723		BOTTOM FRAME ASSY	
F8	5008516		STAND(LEG)	
F9	5008616		FAN MOTOR STAND ASSY	
F10	5013724		PARTITION PLATE	
F11	301232P		COVER (PAINTED)	
F12	301233P		PIPING COVER REAR (PAINTED)	
F13	5013725		STOP VALVE MOUNTING PLATE	
F14	0625252		HANDLE	
P1	5008524		PACKING CASE (BOTTOM ASSY)	
P2	P10012		CUSHION TOP	
P3	5008619		PACKING CASE PRINTING METHOD	