




Número	Referencia	Información	Descripción	Nota
B1	5021207		HEAT EXCHANGER ASSY	
B1-1	119848J		FLARE NUT(FORGING)	
B1-2	1723546		FLARE NUT(FORGING)	
B1-3	091416J		FLARE CAP PACKING	
B1-4	093905J		FLARE CAP PACKING	
B1-5	5021209		LEFT SIDE PANEL	
B1-6	5021210		SOUNDPROOF PUTTY	
B1-7	5018274		PAN HEAD MACHINE SCREW S-TIGHT	
B1-8	170429J		CROSS-RECESSED PAN HEAD TAPPING SCREW	
B1-9	008203J		TRUSS HEAD TAPPING SCREW	
B1-10	5021211		SEALING PLATE (H/E BENDING)	
B1-11	5021212		RUST PREVENTIVE(ANTI-BACILLUS)	
B2	380120		THERMISTOR SET SPRING	
C1	5021213		CROSS FLOW FAN ASSY	
C2			SELECTION BASED ON SERIAL NUMBER, see C2A and C2B	
C2A			Till serial J003696; order C2-2 + F1-6-1	
C2B			From serial J003697; order C2-2	
C2-1	5008272		SHAFT	
C2-2	5032100		DISCH.GRILLE HOR.BLADE (MAIN)	
C3	5021216		DISCH.GRILLE HOR.BLADE (SUB) A	
C3-1	6004993		SHAFT	
E1	5021217		EL.COMPO.BOX	
E2	5021218		PCB ASSY(POWER)	
E3	*		SELECTION BASED ON SERIAL NUMBER-SEE NOTE E3.1 or E	
E3.1	5021220		PCB ASSY(CONTROL)	Till serial J002197
E3.2	5023866		PCB ASSY(CONTROL)	From serial J002198
E4	5021225		INDICATION LAMP COVER	
E5	5021226		PCB ASSY	
E6	5021227		WIRE HARNESS(DISPLAY)	
E7	5021228		COVER(GRID EYE)	
E8	5021229		PCB ASSY	
E9	5021230		WIRE HARNESS(GRID EYE)	
E10	5021231		INDICATION LAMP COVER (OPTICAL	
E11	5021232		MOUNTING PLATE(SENSOR COVER)	
E12	2291035	B27B802	HUMIDITY SENSOR	
E13	5021233		PCB ASSY	
E14	5021234		WI-FI CONTROL CIRCUIT (WLAN C)	
E15	5021235		WIRE HARNESS(HIGH VOLTAGE)	
E16	5021236		WIRE HARNESS(LOW VOLTAGE)	
E17	5021237		EARTH WIRE(TERMINAL STRIP)	
E18	5021238		EARTH WIRE (HEAT EXCHANGER)	
E19	5021239		WIRE HARNESS(SENSOR)	
E20	5021240		WIRE HARNESS(CONNECTION)	
E21	5021241		WIRE HARNESS(WIRELESS)	
E22	5021242		WIRE HARNESS(FOR POWER SOURCE)	
E23	5021243		EARTH WIRE (POWER PCB)	
E24	5021244		WIRE HARNESS(STREAMER)	
E25	5021245		SHIELD PLATE (1)	
E26	5021246		SHIELD PLATE (2) ASSY	
E27	5021247		EARTH PLATE	
E28	5021248		SHIELD PLATE (Terminal rear)	
E29	1724688		TERMINAL STRIP TB-ETX-4PA-D1	
E30	5021249		INSULATION SHEET(RADIATION)	
E31	0812847		WIRE RETAINING BAND	
E32	1748886		PAN HEAD TAPPING SCREW	
E33	121650J		TRUSS HEAD TAPPING SCREW	
E34	5018274		PAN HEAD MACHINE SCREW S-TIGHT	
E35	5021250		THERMISTOR ASSY	
E36	5021251		WIRE SADDLE	
E37	5021252		SEALING MATERIAL	
E38	116718J		FERRITE CORE	
E39	5016531		STREAMER	
F1	5021253		BOTTOM FRAME ASSY	
F1-1	5021254		THERMAL INSULATION (REAR LEFT)	
F1-2	5021255		THERMAL INSULATION (REAR R)	
F1-3	5021256		DRAIN PAN ASSY	
F1-3-1	5021257		DRAIN PAN STABILIZER	
F1-3-2	5021258		DISCH.GRILLE VERT.BLADE	

F1-3-3	5021259		CONNECTING ROD	
F1-4	5021260		AIR OUTLET	
F1-5	5021261		GEAR CASE ASSY(RIGHT)	
F1-6			SELECTION BASED ON SERIAL NUMBER; see F1-6A and F1-6B	
F1-6A			Till serial J003696; order C2-2 + F1-6-1	
F1-6B			From serial J003697; order F1-6-1	
F1-6-1	5032101		GEAR CASE(LEFT)ASSY	
F1-7	5016250		FAN BEARING VIBRATION ABSORBER	
F1-7-1	5016251		BEARING MOUNTING PLATE	
F1-7-2	156867J		FAN BEARING VIBRATION ABSORBER	
F1-8	066228J		DRAINPLUG	
F1-9	5012608		DRAIN HOSE ASSY	
F1-10	5011480		PAN HEAD TAPPING SCREW	
F1-11	170429J		CROSS-RECESSED PAN HEAD TAPPING SCREW	
F1-12	5021263		FAN GUARD ASSY	
F2	5021264		RIGHT SIDE PANEL ASSY	
F3	038006J		TRUSS HEAD MACHINE SCREW	
F4	121650J		TRUSS HEAD TAPPING SCREW	
F5	5021265		AIR FILTER	
F6	5021360		FRONT GRILLE ASSY	
F6-1	5004107		COVER SHAFT	
F6-2	5021269		COVER(SHAFT BEARING)	
F6-3	5021270		COVER RIGHT(DRIVE MECHANISM)AS	
F6-4	5021271		COVER LEFT(DRIVE MECHANISM)ASS	
F6-5	5021272		CONNECTING ROD(RIGHT)	
F6-6	5021273		CONNECTING ROD(LEFT)	
F6-7	5021274		SUPPORT PLATE	
F6-8	5021275		SHAFT(DRIVE SHAFT)	
F6-9	5021276		GEAR DRIVING ASSY(M4S included)	
F6-10	5021278		FRONT GRILLE DECO PLATE	
F6-11	5021280		FRONT GRILLE DECO PLATE	
F6-12	5021282		FRONT GRILLE DECO PLATE	
F6-13	5021284		COVER	
F6-14	5021285		JOINT BAR(LOWER)	
F6-15	5021286		MOUNTING PLATE(LENS)	
F6-16	5021287		DISPLAY DEVICE(PHOTO LENS)	
F6-17	5021288		SWITCH(LED LENDS)	
F6-18	-		PANEL (UPPER) ASSY SEE NOTE	ORDER ASSY ITEM F6
F6-18	-		PANEL (UPPER) ASSY SEE NOTE	ORDER ASSY ITEM F6
F6-18	-		PANEL (UPPER) ASSY SEE NOTE	ORDER ASSY ITEM F6
F6-19	121650J		TRUSS HEAD TAPPING SCREW	
F6-20	-		PANEL(LOWER) ASSY SEE NOTE	ORDER ASSY ITEM F6
F6-20	-		PANEL(LOWER) ASSY SEE NOTE	ORDER ASSY ITEM F6
F6-20	-		PANEL(LOWER) ASSY SEE NOTE	ORDER ASSY ITEM F6
F7	5021295		SEALING PLATE(TOP)	
F8	5021296		PIPING FIXTURE	
F9	5021298		SERVICE COVER ASSY	
F10	5021299		FAN MOTOR STATOR	
F11	5021300		MOTOR COVER BODY ASSY	
F12	5021301		MOTOR COVER (CAP)	
F13	5021302		RUBBER GROMMET	
F14	2341365		FAN BEARING VIBRATION ABSORBER	
F15	5021303		DRIP PROOF PLATE	
K1	5021304		REMOTE CONTROLLER ASSY	
K2	5004122		REMOCON WALL MOUNTING PLATE	
K3	5021305		INSTALLATION PLATE	
K4	5012559		PRODUCT COVER	
K5	5021306		CUSHION(EPS) ASSY	
K6	5021307		PACKING CASE	
K7	5021309		ACCESSORY SET (SCREW COVER)	