

COMPONENTES CAPOTA/INTERRUPTORES



LAM179



LAM180



LAM181



LAM182

Código Code	Descripción Description	Modelo Model	Código original Original code
LAM179	Cojinete Castor	L20, L21, L25, 015, 24L	0800048
LAM180	Adaptador Rod for bearing		0800020
LAM181	Cojinete Ball bearing, joint		0800010
LAM182	Acoplamiento Linkage stub		0800115



LAM183



LAM184

Código Code	Descripción Description	Modelo Model	Código original Original code
LAM183	Muelle Spring	L20, L21, L25, 015, 24L	0800711
LAM184	Maneta Handle	L20	0500049

Interruptores Switches



LAM185



LAM186



LAM187

Código Code	Descripción Description	Modelo Model	Código original Original code
LAM185	Interruptor Main switch, 2-pole, closer	Universal	0301000
LAM186	Interruptor Main switch (drain pump), 2-pole, changer	Minibar, S280, Super QS, 045F, 050F, 075F, 01F, F85, F92, L20, L21, L25, 015, 24L	
LAM187	Interruptor Main switch / drain pump, 2-pole, 1W + 1S	Super QS, S280, 040F, 045F, 050F, S510	0301004



LAM188



LAM189



LAM190

Código Code	Descripción Description	Modelo Model	Código original Original code
LAM188	Pulsador Pushbutton, 2-pole, 2 closer (Softeners)	GS4	0301101
LAM189	Pulsador Pushbutton, 1-pole, 1 closer	S200, Minibar, Super QS, S280, 045F, 050F, S510, GS4, GS6, 040F	0301100
LAM190	Piloto verde 230V Signal lamp / green, 230V	Universal	0300284